



Dell Inspiron 1564 Hard Drive Replacement

This will show how to replace the Hard Drive

Written By: Megan Nelson



INTRODUCTION

Steps on how to remove and replace the hard drive.



TOOLS:

- [64 Bit Driver Kit](#) (1)
-

Step 1 — Hard Drive





- Locate battery latch on bottom of computer and slide to right.
- While holding battery latch pull battery away from device. Battery is now removed.

Step 2



- With J0 screwdriver bit loosen all screws from the backing above the battery latch and remove covering.

Step 3



- Locate the three 4mm screws securing Hard Drive and with a J0 screwdriver unscrew them.
- Slide the Hard Drive to the left to unplug it and gently pry upwards and pull away from device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-25 02:35:47 PM.